



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

YJ BREEZER TOP

INSTALLATION INSTRUCTIONS

WAR 1105 & 1110 / RJR CG507B & CG508B

CJ5 '76-83, CJ7 '76-'86 & '87-'91

NOTE: Installation of this top requires footman loops (provided) on top of rear corners and a retaining channel on the windshield frame. If you do not have a retaining channel it can be purchased at your local offroad shop- Bestop part #51209-01 or OutLand part #90101.

1. Install all hardware
2. Place Breezer Top over windshield frame top side up
3. Fold the front edge over at a 180 degree angle & insert folded webbing strip into windshield channel making sure it is fully in the channel all the way across
NOTE: It may help to use a rubber mallet to tap the strip into the channel – it is a tight fit
4. Pull the Breezer top over the Roll Bar, insert long straps through the footman loops & lace through metal buckles on both sides
5. Recheck that front edge strip is still fully inserted in channel all the way across, if so pull on straps until you have proper tension on the top
6. Loop side tensioning straps under joint where kicker bar meets main bar & cinch until you have proper tension

Your Breezer Top is now fully installed.

Enjoy your new Breezer Top!

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS